



PUMP ASSEMBLY

- 1 Mechanical end
- 2 Clamp ring
- 3 Expeller ring
- 4 Expeller
- 5 Backliner frame seal
- 6 Backliner
- 7 Impeller
- 8 Casing
- 9 Discharge joint ring
- 10 Discharge flange
- 11 Intake flange
- 12 Intake joint ring