



# P U M P A S S E M B L Y

- 1 Adjusting screw
- 2 Bearing assembly
- 3 Clamp washer
- 4 Clamp bolt
- 5 Discharge Y-Piece
- 6 Base
- 7 Column
- 8 Salvic joint
- 9 Shaft O-Ring
- 10 Shaft sleeve
- 11 Impeller O-Ring
- 12 Impeller
- 13 Casing
- 14 Strainer
- 15 Cotter
- 16 Cover plate
- 17 Volute cover seal